

Printer Compatibilities List for TL-PA110U/TL-PS110P/TL-WPS510U

Update:2011-11-02

Note: "OK" means the print server is compatible with the printer;
 " \ " means the print server is not compatible with the printer;
 "—" means the function is not tested;

The product only support the **printing funtion** of the Multi Function Printer.

No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
1	HP	Business InkJet 1000	OK		OK
2	HP	Color Laserjet 1500L	OK		
3	HP	Color Laserjet 1600	OK		OK
4	HP	Color Laserjet 2500	OK	OK	OK
5	HP	Color LaserJet 2550	OK	OK	OK
6	HP	Color LaserJet 2550L/LN	OK		OK
7	HP	Color LaserJet 2600	OK		OK
8	HP	Color LaserJet 2605	OK	OK	OK
9	HP	Color LaserJet 2700n	OK		OK
10	HP	Color LaserJet 2840	OK		OK
11	HP	Color LaserJet 3700	OK	OK	OK
12	HP	Color LaserJet 4000		OK	
13	HP	Color LaserJet 4100		OK	
14	HP	Color LaserJet 4500		OK	
15	HP	Color Laserjet 4650	OK	OK	OK
16	HP	Color LaserJet 8550 Color Laser		OK	
17	HP	Color Laserjet CP1215	OK		OK
18	HP	Color Laserjet CM1312 MFP	OK		OK
19	HP	Color Laserjet CM1015 MFP	OK		OK
20	HP	Designjet 100	OK	OK	OK
21	HP	Designjet 600		OK	
22	HP	Designjet 650C		OK	
23	HP	Designjet 700		OK	
24	HP	Designjet 750C+		OK	
25	HP	DeskJet 1120C		OK	
26	HP	Deskjet 1125C	OK	OK	OK
27	HP	Deskjet 1180C	OK	OK	OK
28	HP	DeskJet 1280	OK	OK	OK
29	HP	Deskjet 2000 J210	OK		OK
30	HP	Deskjet 3000	OK		OK
31	HP	Deskjet 3050	OK		OK
32	HP	Deskjet 3325	OK		OK
33	HP	DeskJet 3420	OK		OK
34	HP	Deskjet 3535	OK		OK
35	HP	Deskjet 3650	OK		OK
36	HP	Deskjet 3743	OK		OK
37	HP	Deskjet 3748	OK		OK
38	HP	Deskjet 3820	OK	OK	OK
39	HP	DeskJet 3920	OK		OK
40	HP	DeskJet 3940	OK		OK
41	HP	DeskJet 400/420		OK	
42	HP	Deskjet 450C	OK	OK	OK
43	HP	DeskJet 5440	OK		OK
44	HP	DeskJet 5500		OK	
45	HP	Deskjet 5550	OK	OK	OK
46	HP	Deskjet 5652	OK	OK	OK
47	HP	Deskjet 670C		OK	
48	HP	Deskjet 680C		OK	
49	HP	Deskjet 690C		OK	
50	HP	Deskjet 720C		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
51	HP	Deskjet 810C	OK	OK	OK
52	HP	Deskjet 830C	OK	OK	OK
53	HP	Deskjet 845C	OK		OK
54	HP	DeskJet 9300	OK	OK	OK
55	HP	Deskjet 948c	OK	OK	OK
56	HP	Deskjet 9600	OK	OK	OK
57	HP	Deskjet 9650	OK	OK	OK

58	HP	Deskjet 970c XI	OK	OK	OK
59	HP	Deskjet 9800	OK	OK	OK
60	HP	Deskjet D1560	OK		OK
61	HP	Deskjet D2560	OK		OK
62	HP	Deskjet D5560	OK		OK
63	HP	DeskJet F370	OK		OK
64	HP	DeskJet F380	OK		OK
65	HP	DeskJet F4185	OK		OK
66	HP	DeskJet F4280	OK		OK
67	HP	Deskjet F4480	OK		OK
68	HP	Laserjet M1005 MFP	OK		OK
69	HP	LaserJet 1022	OK		OK
70	HP	LaserJet 1022N	OK		OK
71	HP	Laserjet 1100		OK	
72	HP	Laserjet 1010	OK		
73	HP	LaserJet 1160	OK	OK	OK
74	HP	LaserJet 1200	OK	OK	OK
75	HP	LaserJet 1220	OK	OK	OK
76	HP	Laserjet 1300	OK	OK	OK
77	HP	Laserjet 1320	OK	OK	OK
78	HP	Laserjet M1522n MFP	OK		OK
79	HP	LaserJet 2100		OK	
80	HP	Laserjet 2200d	OK	OK	OK
81	HP	Laserjet 2300	OK	OK	OK
82	HP	LaserJet 2410	OK	OK	OK
83	HP	LaserJet 2420	OK	OK	OK
84	HP	LaserJet 2550	OK	OK	OK
85	HP	LaserJet 3015	OK	OK	OK
86	HP	LaserJet 3050	OK		OK
87	HP	LaserJet 3055	OK		OK
88	HP	Laserjet 3200	OK	OK	OK
89	HP	Laserjet 3330	OK	OK	OK
90	HP	LaserJet 3330mfp	OK	OK	OK
91	HP	LaserJet 3380	OK		OK
92	HP	Laserjet 4000		OK	
93	HP	LaserJet 4050		OK	
94	HP	Laserjet 4100 /4100n		OK	
95	HP	LaserJet 4250	OK	OK	OK
96	HP	Laserjet 4300n		OK	
97	HP	Laserjet 4300tn/dtn		OK	
98	HP	Laserjet 4500		OK	
99	HP	Laserjet 4650	OK	OK	OK
100	HP	Laserjet 5100fn/tn		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
101	HP	Laserjet 5100le/se		OK	
102	HP	Laserjet 6P / 6L		OK	
103	HP	Laserjet 8100		OK	
104	HP	Laserjet M1005	OK		OK
105	HP	Laserjet M1005 MFP			
106	HP	Laserjet M1120 MFP	OK		OK
107	HP	LaserJet M1319F MFP	OK		OK
108	HP	LaserJet P2015	OK		OK
109	HP	OfficeJet J3608	OK		OK
110	HP	OfficeJet 4255	OK		OK
111	HP	OfficeJet 4255	OK		OK
112	HP	OfficeJet 4315	OK		OK
113	HP	OfficeJet 4500	OK		OK
114	HP	OfficeJet 5610	OK		OK
115	HP	OfficeJet J5780	OK		OK
116	HP	OfficeJet 6210	OK		OK
117	HP	OfficeJet 6310	OK		OK
118	HP	OfficeJet 6000	OK		OK
119	HP	OfficeJet 6500	OK		OK
120	HP	OfficeJet 7000			OK
121	HP	OfficeJet 7500A	OK		OK

122	HP	OfficeJet 7210	OK		OK
123	HP	OfficeJet J4580	OK		OK
124	HP	OfficeJet J4660	OK		OK
125	HP	OfficeJet J6480	OK		OK
126	HP	OfficeJet K7100	OK		OK
127	HP	OfficeJet K850	OK	OK	OK
128	HP	OfficeJet Pro K5300	OK		OK
129	HP	OfficeJet Pro K550	OK		OK
130	HP	OfficeJet Pro K8600	OK		OK
131	HP	OfficeJet Pro L7380	OK		OK
132	HP	OfficeJet Pro L7590	OK		OK
133	HP	OfficeJet Pro 6500A Plus	OK		OK
134	HP	OfficeJet Pro 7000	OK		OK
135	HP	OfficeJet Pro 8000	OK		OK
136	HP	OfficeJet Pro 8500A Plus	OK		OK
137	HP	OfficeJet Pro 8500W	OK		OK
138	HP	Photosmart 2610	OK		OK
139	HP	Photosmart 3110	OK		OK
140	HP	Photosmart 7150	OK		OK
141	HP	Photosmart 7200	OK		OK
142	HP	Photosmart 7550	OK		OK
143	HP	Photosmart 7660	OK		OK
144	HP	Photosmart 7830	OK		OK
145	HP	Photosmart 7900	OK		OK
146	HP	Photosmart 8200	OK		OK
147	HP	Photosmart Plus B209a	OK		OK
148	HP	Photosmart Plus B210a	OK		OK
149	HP	Photosmart Plus C310a	OK		OK
150	HP	Photosmart A520	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
151	HP	Photosmart B109a	OK		OK
152	HP	Photosmart B110a AIO	OK		OK
153	HP	Photosmart C309a	OK		OK
154	HP	Photosmart C410a	OK		OK
155	HP	Photosmart C3180	OK		OK
156	HP	Photosmart C4180	OK		OK
157	HP	Photosmart C4280	OK		OK
158	HP	Photosmart C4385	OK		OK
159	HP	Photosmart C4480	OK		OK
160	HP	Photosmart C4580	OK		OK
161	HP	Photosmart C5180	OK		OK
162	HP	Photosmart C5280	OK		OK
163	HP	Photosmart C5380	OK		OK
164	HP	Photosmart C6180	OK		OK
165	HP	Photosmart C6280	OK		OK
166	HP	Photosmart C6380	OK		OK
167	HP	Photosmart C7180	OK		OK
168	HP	Photosmart C7280	OK		OK
169	HP	Photosmart C8180	OK		OK
170	HP	Photosmart D5160	OK		OK
171	HP	Photosmart D5360	OK		OK
172	HP	Photosmart D5460	OK		OK
173	HP	Photosmart D7160	OK		OK
174	HP	Photosmart D7260	OK		OK
175	HP	Photosmart D7360	OK		OK
176	HP	Photosmart Premium C309g	OK		OK
177	HP	Photosmart Premium C310g	OK		OK
178	HP	PSC 1210			OK
179	HP	PSC 1315	OK		OK
180	HP	PSC 1350	OK		OK
181	HP	PSC 1410	OK		OK
182	HP	PSC 1610	OK		OK
183	HP	PSC 2210	OK		OK
184	HP	PSC 2310	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U

185	EPSON	Aculaser C1100SE	OK	OK	OK
186	EPSON	Aculaser C1700	OK		OK
187	EPSON	Aculaser C1750N	OK		OK
188	EPSON	Aculaser C1750W	OK		OK
189	EPSON	Aculaser C1900	OK	OK	OK
190	EPSON	Aculaser C2900	OK		OK
191	EPSON	Aculaser C3800	OK		OK
192	EPSON	Aculaser C3900N	OK		OK
193	EPSON	Aculaser C9100	OK		OK
194	EPSON	Aculaser CX16NF	OK		OK
195	EPSON	Aculaser CX17NF	OK		OK
196	EPSON	Aculaser M1400	OK		OK
197	EPSON	Aculaser M2010DN	OK		OK
198	EPSON	Aculaser M2010D	OK	OK	OK
199	EPSON	Aculaser M2310D	OK	OK	OK
200	EPSON	Aculaser M2310DN	OK		OK
201	EPSON	Aculaser M2410D	OK	OK	OK
202	EPSON	Aculaser M2410DN	OK		OK
203	EPSON	Aculaser MX14	OK		OK
204	EPSON	Aculaser MX14NF	OK		OK
205	EPSON	B-508DN	OK		OK
206	EPSON	C750	OK	OK	OK
207	EPSON	CC-500L	OK		OK
208	EPSON	CL-760	OK		OK
209	EPSON	E-300L	OK		OK
210	EPSON	E-520	OK		OK
211	EPSON	E-720	OK		OK
212	EPSON	EC-01	OK		OK
213	EPSON	EPL 5700		OK	
214	EPSON	EPL 5700		OK	
215	EPSON	EPL 5800	OK	OK	OK
216	EPSON	EPL 5800	OK	OK	OK
217	EPSON	EPL 5900	OK	OK	OK
218	EPSON	EPL 5900	OK	OK	OK
219	EPSON	EPL 6100	OK	OK	OK
220	EPSON	EPL 6200	OK	OK	OK
221	EPSON	Aculaser C1600	OK		OK
222	EPSON	B-518DN	OK		OK
223	EPSON	EPL 6200	OK	OK	OK
224	EPSON	EPL N2120		OK	
225	EPSON	K100	OK		OK
226	EPSON	L200	OK		OK
227	EPSON	L800	OK		OK
228	EPSON	LP2500	OK		OK
229	EPSON	LP-7700	OK		OK
230	EPSON	LP-8700	OK		OK
231	EPSON	LP-8800C	OK		OK
232	EPSON	LP8900	OK		OK
233	EPSON	LP-9500C	OK		OK
234	EPSON	LQ 100		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
235	EPSON	LQ 1000C		OK	
236	EPSON	LQ 1170+		OK	
237	EPSON	LQ 1170C		OK	
238	EPSON	LQ 1170C+		OK	
239	EPSON	LQ 2070C		OK	
240	EPSON	LQ 2080C		OK	
241	EPSON	LQ 2090		OK	
242	EPSON	LQ 2090C	OK	OK	OK
243	EPSON	LQ 2170C		OK	
244	EPSON	LQ 2180C		OK	
245	EPSON	LQ 2190C	OK	OK	OK
246	EPSON	LQ 2550		OK	
247	EPSON	LQ 300		OK	
248	EPSON	LQ 300+		OK	
249	EPSON	LQ 300+II	OK	OK	OK
250	EPSON	LQ 3500C		OK	

251	EPSON	LQ 570C		OK	
252	EPSON	LQ 670		OK	
253	EPSON	LQ 680		OK	
254	EPSON	LQ 680C		OK	
255	EPSON	ME 320	OK		OK
256	EPSON	ME 340	OK		OK
257	EPSON	ME Office 82WD	OK		OK
258	EPSON	ME Office 900WD	OK		OK
259	EPSON	ME Office 940FW	OK		OK
260	EPSON	ME Office 960FWD	OK		OK
261	EPSON	MC-2000	OK		OK
262	EPSON	PictureMate PM250	OK		OK
263	EPSON	PLQ-20C	OK		OK
264	EPSON	PLQ-20CM	OK		OK
265	EPSON	PM-860PT	OK		OK
266	EPSON	PM-890C	OK		OK
267	EPSON	PM-920C	OK		OK
268	EPSON	PM-930C	OK		OK
269	EPSON	PM-950C	OK		OK
270	EPSON	PM-970C	OK		OK
271	EPSON	PM-980C	OK		OK
272	EPSON	PM-A550	OK		OK
273	EPSON	PM-A620	OK		OK
274	EPSON	PM-A650	OK		OK
275	EPSON	PM-A720	OK		OK
276	EPSON	PM-A820	OK		OK
277	EPSON	PM-A840	OK		OK
278	EPSON	PM-A850	OK		OK
279	EPSON	PM-A890	OK		OK
280	EPSON	PM-A900	OK		OK
281	EPSON	PM-A920	OK		OK
282	EPSON	PM-A940	OK		OK
283	EPSON	PM-A950	OK		OK
284	EPSON	PM-A970	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
285	EPSON	PM-2200C	OK		OK
286	EPSON	PM-3500C	OK		OK
287	EPSON	PM-3700C	OK		OK
288	EPSON	PM-4000PX	OK		OK
289	EPSON	PM-D800	OK		OK
290	EPSON	PM-D870	OK		OK
291	EPSON	PM-D1000	OK		OK
292	EPSON	PM-FA700	OK		OK
293	EPSON	PM-G800	OK		OK
294	EPSON	PM-G820	OK		OK
295	EPSON	PM-G850	OK		OK
296	EPSON	PM-G860	OK		OK
297	EPSON	PM-G4500	OK		OK
298	EPSON	PM-T960	OK		OK
299	EPSON	PM-T990	OK		OK
300	EPSON	PX-5000	OK		OK
301	EPSON	PX-A640	OK		OK
302	EPSON	PX-A740	OK		OK
303	EPSON	PX-G5300	OK		OK
304	EPSON	PX-G5100	OK		OK
305	EPSON	PX-G930	OK		OK
306	EPSON	PX-G5000	OK		OK
307	EPSON	PX-V780	OK		OK
308	EPSON	RX 510	OK		OK
309	EPSON	RX 530	OK		OK
310	EPSON	RX 590	OK		OK
311	EPSON	RX 630	OK		OK
312	EPSON	RX 690	OK		OK
313	EPSON	Stylus C20	OK		OK
314	EPSON	Stylus C40	OK		OK
315	EPSON	Stylus C41UX/SX	OK		OK
316	EPSON	Stylus C43UX	OK		OK

317	EPSON	Stylus C45	OK		OK
318	EPSON	Stylus C59	OK		OK
319	EPSON	Stylus C60	OK	OK	OK
320	EPSON	Stylus C63	OK	OK	OK
321	EPSON	Stylus C67	OK	OK	OK
322	EPSON	Stylus C79	OK		OK
323	EPSON	Stylus C83		OK	
324	EPSON	Stylus C90	OK		OK
325	EPSON	Stylus Color 1160	OK		OK
326	EPSON	Stylus Color 1500	OK		OK
327	EPSON	Stylus Color 1520	OK		OK
328	EPSON	Stylus Color 400		OK	
329	EPSON	Stylus Color 600		OK	
330	EPSON	Stylus Color 670	OK	OK	OK
331	EPSON	Stylus Color 800	OK	OK	OK
332	EPSON	Stylus Color 810	OK	OK	OK
333	EPSON	Stylus Color 850	OK	OK	OK
334	EPSON	Stylus Color 900	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
335	EPSON	Stylus CX-1500	OK		OK
336	EPSON	Stylus CX-2900	OK		OK
337	EPSON	Stylus CX-3500	OK		OK
338	EPSON	Stylus CX-3700	OK		OK
339	EPSON	Stylus CX-3900	OK		OK
340	EPSON	Stylus CX-4100	OK		OK
341	EPSON	Stylus CX-4700	OK		OK
342	EPSON	Stylus CX-4900	OK		OK
343	EPSON	Stylus CX-5300	OK		OK
344	EPSON	Stylus CX-5500	OK		OK
345	EPSON	Stylus CX-5505	OK		OK
346	EPSON	Stylus CX-5900	OK		OK
347	EPSON	Stylus CX-6900F	OK		OK
348	EPSON	Stylus CX-7300	OK		OK
349	EPSON	Stylus CX-7800	OK		OK
350	EPSON	Stylus CX-8300	OK		OK
351	EPSON	Stylus CX-9300F	OK		OK
352	EPSON	Stylus Office T30	OK		OK
353	EPSON	Stylus Office T40W	OK		OK
354	EPSON	Stylus Office TX300F	OK		OK
355	EPSON	Stylus Office TX320F	OK		OK
356	EPSON	Stylus Office TX510FN	OK		OK
357	EPSON	Stylus Office TX600FW	OK		OK
358	EPSON	Stylus Office TX610FW	OK		OK
359	EPSON	Stylus Office T1100	OK		OK
360	EPSON	Stylus Photo 915	OK		OK
361	EPSON	Stylus Photo 1270	OK	OK	OK
362	EPSON	Stylus Photo 1290	OK		OK
363	EPSON	Stylus Photo 1390	OK		OK
364	EPSON	Stylus Photo 2100	OK		OK
365	EPSON	Stylus Photo 710	OK		OK
366	EPSON	Stylus Photo 720	OK		OK
367	EPSON	Stylus Photo 790	OK		OK
368	EPSON	Stylus Photo 810	OK	OK	OK
369	EPSON	Stylus Photo 830U	OK		OK
370	EPSON	Stylus Photo 900	OK	OK	OK
371	EPSON	Stylus Photo 915	OK		OK
372	EPSON	Stylus Photo EX2	OK	OK	OK
373	EPSON	Stylus Photo EX3	OK	OK	OK
374	EPSON	Stylus Photo R1800	OK	OK	OK
375	EPSON	Stylus Photo R210	OK		OK
376	EPSON	Stylus Photo R230	OK		OK
377	EPSON	Stylus Photo R250	OK		OK
378	EPSON	Stylus Photo R270	OK		OK
379	EPSON	Stylus Photo R310	OK		OK
380	EPSON	Stylus Photo R350	OK		OK
381	EPSON	Stylus Photo R2400	OK		OK
382	EPSON	Stylus Photo R800	OK		OK

383	EPSON	Stylus Photo RX430	OK		OK
384	EPSON	Stylus Photo RX 510	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
385	EPSON	Stylus Photo RX 530	OK		OK
386	EPSON	Stylus Photo RX 590	OK		OK
387	EPSON	Stylus Photo RX 630	OK		OK
388	EPSON	Stylus Photo RX 650	OK		OK
389	EPSON	Stylus Photo RX 690	OK		OK
390	EPSON	Stylus Photo R2880	OK		OK
391	EPSON	Stylus Photo TX700W	OK		OK
392	EPSON	Stylus Photo TX800FW	OK		OK
393	EPSON	Stylus Photo TX820FWD	OK		OK
394	EPSON	Stylus Pro 7600	OK	OK	OK
395	EPSON	Stylus TX550W	OK		OK
396	EPSON	Stylus TX420W	OK		OK
397	EPSON	Stylus TX410	OK		OK
398	EPSON	Stylus TX430	OK		OK
399	EPSON	Stylus TX235	OK		OK
400	EPSON	Stylus TX220	OK		OK
401	EPSON	Stylus TX200	OK		OK
402	EPSON	Stylus TX210	OK		OK
403	EPSON	Stylus TX130	OK		OK
404	EPSON	Stylus TX110	OK		OK
405	EPSON	Stylus TX100	OK		OK
406	EPSON	Stylus T22	OK		OK
407	EPSON	Stylus T20	OK		OK
408	EPSON	Stylus T21	OK		OK
409	EPSON	Stylus Photo T50	OK		OK
410	EPSON	TM883 (III)		OK	
411	EPSON	TM T88III		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
412	Canon	BJ-330		OK	
413	Canon	BJC-4200		OK	
414	Canon	BJC-4300		OK	
415	Canon	BJC-4500			
416	Canon	BJC-4550		OK	
417	Canon	BJC-4600		OK	
418	Canon	BJF9000	OK		OK
419	Canon	D380	OK		OK
420	Canon	I-255	OK		OK
421	Canon	I-355	OK		OK
422	Canon	I-450	OK		OK
423	Canon	I-455	OK		OK
424	Canon	I-470D	OK		OK
425	Canon	I-475D	OK		OK
426	Canon	I-550	OK		OK
427	Canon	I-560	OK		OK
428	Canon	I-850	OK		OK
429	Canon	I-865	OK		OK
430	Canon	I-950	OK		OK
431	Canon	I-6100	OK	OK	OK
432	Canon	I-6500	OK	OK	OK
433	Canon	I-9100	OK		OK
434	Canon	I-9950	OK		OK
435	Canon	IX4000	OK		OK
436	Canon	IX5000	OK		OK
437	Canon	Imageclass D380	OK		OK
438	Canon	MP-160	OK		OK
439	Canon	MP-638	OK		OK
440	Canon	MP 770	OK		OK
441	Canon	MX318	OK		OK
442	Canon	MX320	OK		OK
443	Canon	MX700	OK		OK
444	Canon	PIXUS IP2500	OK		OK
445	Canon	PIXUS 990i	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
446	Canon	PIXMA iP1000	OK		OK

447	Canon	PIXMA iP1700	OK		OK
448	Canon	PIXMA iP1800	OK		OK
449	Canon	PIXMA Ip1880	OK		OK
450	Canon	PIXMA Ip1980	OK		OK
451	Canon	PIXMA Ip2000	OK		OK
452	Canon	PIXMA iP3000	OK		OK
453	Canon	PIXMA Ip3300	OK		OK
454	Canon	PIXMA Ip3500	OK		OK
455	Canon	PIXMA Ip3680	OK		OK
456	Canon	PIXMA iP4000	OK	OK	OK
457	Canon	PIXMA Ip4200	OK		OK
458	Canon	PIXMA Ip4300	OK		OK
459	Canon	PIXMA Ip4500	OK		OK
460	Canon	PIXMA Ip4760	OK		OK
461	Canon	PIXMA Ip5000	OK		OK
462	Canon	PIXMA Ip6000	OK		OK
463	Canon	PIXMA Ip8500	OK		OK
464	Canon	PIXMA MG6170	OK		OK
465	Canon	PIXMA MP110	OK		OK
466	Canon	PIXMA MP130	OK		OK
467	Canon	PIXMA MP145	OK		OK
468	Canon	PIXMA MP150	OK		OK
469	Canon	PIXMA MP180	OK		OK
470	Canon	PIXMA MP258	OK		OK
471	Canon	PIXMA MP450	OK		OK
472	Canon	PIXMA MP730	OK		OK
473	Canon	PIXMA MP780	OK		OK
474	Canon	PIXMA MP830	OK		OK
475	Canon	PIXMA MX357	OK		OK
476	Canon	PIXMA MX416	OK		OK
477	Canon	S-200SPX	OK		OK
478	Canon	S-520		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
479	Lexmark	C720		OK	
480	Lexmark	E230	OK		OK
481	Lexmark	E322	OK	OK	OK
482	Lexmark	Optra S1250		OK	
483	Lexmark	P4350	OK		OK
484	Lexmark	P6250	OK		OK
485	Lexmark	T420	OK	OK	OK
486	Lexmark	T620	OK	OK	OK
487	Lexmark	W812	OK	OK	OK
488	Lexmark	Z42	OK		OK
489	Lexmark	Z43	OK	OK	OK
490	Lexmark	Z45	OK		OK
491	Lexmark	Z55	OK	OK	OK
492	Lexmark	Z515	OK	OK	OK
493	Lexmark	Z615	OK		OK
494	Lexmark	Z705	OK	OK	OK
495	FUJI Xerox	Able 3321		OK	
496	FUJI Xerox	DL700		OK	
497	FUJI Xerox	DL900		OK	
498	FUJI Xerox	DL-3400		OK	
499	FUJI Xerox	DL-3800		OK	
500	FUJI Xerox	DL-3850		OK	
501	FUJI Xerox	DL-5800		OK	
502	FUJI Xerox	DL-6400Pro		OK	
503	FUJI Xerox	DL-6800		OK	
504	FUJI Xerox	DocuPrint 2050	OK	OK	OK
505	FUJI Xerox	DocuPrint 240A	OK	OK	OK
506	FUJI Xerox	DocuPrint C1110B	OK		OK
507	FUJI Xerox	DocuPrint CM205 f	OK		OK
508	FUJI Xerox	DocuPrint CP105 b	OK		OK
509	FUJI Xerox	DocuPrint P205 b	OK		OK
510	FUJI Xerox	DocuPrint M205 b	OK		OK
511	FUJI Xerox	DocuPrint M205 f	OK		OK
512	FUJI Xerox	DocuPrint M205 fw	OK		OK

513	FUJI Xerox	FP 410		OK	
514	FUJI Xerox	Jet Wind 500C		OK	
515	FUJI Xerox	Phaser 3310	OK	OK	OK
516	FUJI Xerox	PP 10		OK	
517	Konica Minolta	Di 152		OK	
518	Konica Minolta	Di 200/Di 250/Di 251		OK	
519	Konica Minolta	magicolor 2450	OK	OK	OK
520	Konica Minolta	magicolor 5450	OK	OK	OK
521	Konica Minolta	magicolor 7300	OK		OK
522	Konica Minolta	Magicolor 7300	OK		OK
523	Konica Minolta	PagePro 1350W	OK		OK
524	Konica Minolta	PagePro 9100	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
525	Samsung	CLP-315	OK		OK
526	Samsung	CLP-500	OK	OK	OK
527	Samsung	CLP-510	OK	OK	OK
528	Samsung	CLP-620ND	OK		OK
529	Samsung	CLX2160	OK		OK
530	Samsung	ML-1510/1710	OK	OK	OK
531	Samsung	ML-1520	OK		OK
532	Samsung	ML-1660	OK		OK
533	Samsung	ML-1710	OK		OK
534	Samsung	ML-1750	OK	OK	OK
535	Samsung	ML-1915	OK		OK
536	Samsung	ML-2010	OK		OK
537	Samsung	ML-2250	OK	OK	OK
538	Samsung	ML-2550	OK	OK	OK
539	Samsung	ML-2580N	OK		OK
540	Samsung	ML-3471ND	OK	OK	OK
541	Samsung	SCX-4016	OK	OK	OK
542	Samsung	SCX-4100/4106/4116/4216F	OK	OK	OK
543	Samsung	SCX-4300			OK
544	Samsung	SCX-4623			OK
545	Samsung	SRP 270		OK	
546	Panasonic	KX-P1121		OK	
547	Panasonic	KX-P1123		OK	
548	Panasonic	KX-P1124		OK	
549	Panasonic	KX-P1624		OK	
550	Panasonic	KX-P6500		OK	
551	TOSHIBA	E-161	OK(Parallel only)	OK	OK
552	TOSHIBA	Estudio-25		OK	
553	NEC	NEC P2200		OK	
554	NEC	NEC P3200		OK	
555	NEC	NEC P5300		OK	
556	NEC	NEC P8000		OK	
557	IBM	IBM Inforprint 20		OK	
558	IBM	Infoprint 1116	OK	OK	OK
559	IBM	Infoprint 1312	OK	OK	OK
560	IBM	Infoprint 1316	OK	OK	OK
561	IBM	Infoprint 1332	OK	OK	OK
562	IBM	Infoprint 1412	OK	OK	OK
563	Star	NX-2420		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
564	Sharp	AR-255		OK(Parallel only)	
565	Sharp	AR-265FG		OK(Parallel only)	
566	Sharp	AR-M160(AR-NB2)		OK(Parallel only)	
567	Sharp	AR-M205		OK(Parallel only)	
568	Sharp	AR-M207		OK(Parallel only)	
569	Sharp	AR-M209			
570	Sharp	AR-M235		OK(Parallel only)	
571	Sharp	AR-M236			
572	Sharp	AR-M275		OK(Parallel only)	
573	Sharp	AR-M276			
574	Sharp	AR-M350		OK(Parallel only)	
575	Sharp	AR-M400		OK(Parallel only)	
576	Sharp	AR-M450		OK(Parallel only)	
577	Sharp	AR-5516			OK

578	RICOH	NF3570		OK	
579	Brother	MFC 4800	OK	OK	OK
580	Brother	MFC 4800J	OK	OK	OK
581	Brother	MFC 6800	OK	OK	OK
582	Brother	MFC 7220	OK	OK	OK
583	Brother	MFC 7420	OK	OK	OK
584	Brother	MFC 7820N	OK	OK	OK
585	Brother	MFC 8840D	OK	OK	OK
586	Brother	MFC 210C	OK		OK
587	Brother	MFC 240C	OK		OK
588	Brother	DCP-7030	OK		OK
589	Brother	HL1260		OK	
590	Brother	HL-2040			
591	Brother	HL-2140	OK		OK
592	Brother	HL-2170W	OK		OK
593	Brother	IntelliFax 2820	OK		OK
594	Zhendan	AD-166			
595	Zhendan	AD-216			
596	Zhendan	AD-226			
597	DELL	DELL 1100			
598	Zonerich	AB-80K			
599	OKI	OKI 5530			
600	OKI	OKI Microline 391		OK	
601	OKI	OKI B4350	OK	OK	OK
602	Jicheng	Jicheng 5890			
603	MITAC	MITAC		OK	
604	BENQ	BENQ CM3000	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
605	Avision	MF 3200	OK		OK
606	Avision	MF 3230	OK		OK
607	Citizen	GSX230		OK	
608	DATAMAX	I-4208		OK	
609	DATAMAX	I-4308		OK	
610	DOCUJET	1610F	OK	OK	OK
611	DOCUJET	UA1610	OK	OK	OK
612	FUTEK	F8000		OK	
613	FUTEK	F84+		OK	
614	FUTEK	F86+		OK	
615	Kyocera	FS-1010	OK	OK	OK
616	Kyocera	FS-1010KX	OK		OK
617	Kyocera	FS-1020	OK	OK	OK
618	Kyocera	FS-1920	OK	OK	OK
619	Kyocera	FS-2000D	OK	OK	OK
620	Kyocera	FS-820	OK	OK	OK
621	Kyocera	FS-920	OK	OK	OK
622	Kyocera	FS-6020	OK	OK	OK
623	Kyocera	FS-6026	OK	OK	OK