

# TL-PS310U Compatibility List

(2011-12-22)

MFP / Printer / Scanner										
No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
1	Avision	MF3200	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
2	Avision	MF3230	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
3	BenQ	CM3000	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
4	BenQ	CM3500	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
5	Brother	DCP-7030	Pass	Pass	N/A	Pass				
6	Brother	HL 2040	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
7	Brother	HL 2170W	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
8	Brother	HL 2140	Pass	N/A	N/A	Pass				
9	Brother	HL 2170W	Pass	N/A	N/A	Pass				
10	Brother	HL 5250DN	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
11	Brother	IntelliFax2820	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
12	Brother	MFC-210C	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
13	Brother	MFC-240C	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
14	Brother	MFC-3820cn	Pass	Pass	-	Pass	Pass	Pass	-	Pass
15	Brother	MFC-3320cn	Pass	N/A	-	Pass	-	N/A	-	Pass
16	Brother	MFC-4800MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
17	Brother	MFC-4800J MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
18	Brother	MFC-6800 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
19	Brother	MFC-7220 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
20	Brother	MFC-7420 MFP	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
21	Brother	MFC-7820N MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
22	Brother	MFC-8440 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
23	Brother	MFC-8840 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
24	Brother	MFC-8840D MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
25	Brother	QL-500	Pass	-	-	-	Pass	-	-	-
26	Canon	CanonScan Lide 5.0	N/A	Pass	N/A	-	N/A	Pass	N/A	-
27	Canon	D660	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
28	Canon	i560	Pass	-	-	-	Pass	-	-	-
29	Canon	ImageClass MF3110	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
30	Canon	ImageClass MF3112	-	-	-	Pass	-	-	-	Pass
31	Canon	ImageClass MF3220	-	-	-	Pass	-	-	-	Pass
32	Canon	ImageClass MF3222	-	-	-	Pass	-	-	-	Pass
33	Canon	ImageClass MF4010	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
34	Canon	ImageClass MF4150	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
35	Canon	iP100	-	-	-	Pass	-	-	-	Pass
36	Canon	iP1700	Pass	N/A	N/A	-	Pass	N/A	N/A	-
37	Canon	IP1980	Pass	N/A	N/A	Pass				
38	Canon	iP2500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
39	Canon	iP2600	Pass	N/A	N/A	-	Pass	N/A	N/A	-
40	Canon	iP3300	Pass	N/A	N/A	-	Pass	N/A	N/A	-
41	Canon	iP3500	Pass	N/A	N/A	-	Pass	N/A	N/A	-

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
42	Canon	iP3600	Pass	N/A	N/A	-	Pass	N/A	N/A	-
43	Canon	iP3680	Pass	N/A	N/A	Pass				
44	Canon	iP4200	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
45	Canon	iP4300	Pass	N/A	N/A	-	-	N/A	N/A	-
46	Canon	iP4500	Pass	N/A	N/A	-	Pass	N/A	N/A	-
47	Canon	iP4600	Pass	N/A	N/A	-	Pass	N/A	N/A	-
48	Canon	iP4760	Pass	N/A	N/A	Pass				
49	Canon	iP5000	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
50	Canon	iP6700D	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
51	Canon	iP7500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
52	Canon	iP90	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
53	Canon	iP90v	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
54	Canon	iX5000	Pass	N/A	N/A	-	Pass	N/A	N/A	-
55	Canon	LBP 1100	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
56	Canon	LBP 1120	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
57	Canon	LBP 1120K	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
58	Canon	LBP 1210	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
59	Canon	LBP 3000	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
60	Canon	LBP 3200	N/A	N/A	N/A	N/A	Pass	N/A	N/A	N/A
61	Canon	LBP 3300	N/A	N/A	N/A	N/A	Pass	N/A	N/A	N/A
62	Canon	LBP 3700	Pass	N/A	N/A	Pass	N/A	N/A	N/A	N/A
63	Canon	MG6170	Pass	Pass	Pass	Pass				
64	Canon	LBP 430W	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
65	Canon	LBP 510	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
66	Canon	LBP 660	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
67	Canon	LBP 800	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
68	Canon	LBP 810	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
69	Canon	MF3110	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
70	Canon	MP4150	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
71	Canon	MP110	-	-	-	Pass	-	-	-	Pass
72	Canon	MP130	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
73	Canon	MP145	-	-	-	Pass	-	-	-	Pass
74	Canon	MP150	Pass	Pass	N/A	Pass	-	-	N/A	Pass
75	Canon	MP160	-	-	-	Pass	-	-	-	Pass
76	Canon	MP170	-	-	-	Pass	-	-	-	Pass
77	Canon	MP180	-	-	-	Pass	-	-	-	Pass
78	Canon	MP198	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
79	Canon	MP258	Pass	Pass	N/A	Pass				
80	Canon	MP450	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
81	Canon	MP460	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
82	Canon	MP470	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
83	Canon	MP480	Pass	Pass	Pass	-	Pass	Pass	Pass	-
84	Canon	MP510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
85	Canon	MP520	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
86	Canon	MP540	Pass	Pass	Pass	-	Pass	Pass	Pass	-

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
87	Canon	MP600	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
88	Canon	MP610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
89	Canon	MP620	Pass	Pass	Pass	-	Pass	Pass	Pass	-
90	Canon	MP630	Pass	Pass	Pass	-	Pass	Pass	Pass	-
91	Canon	MP638	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
92	Canon	MP730	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
93	Canon	MP770	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
94	Canon	MP780	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
95	Canon	MP810	Pass	Pass	-	Pass	-	-	-	Pass
96	Canon	MP830	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
97	Canon	MP960	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
98	Canon	MP970	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
99	Canon	MP980	Pass	Pass	Pass	-	Pass	Pass	Pass	-
100	Canon	MX308	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
101	Canon	MX357	Pass	Pass	N/A	Pass				
102	Canon	MX416	Pass	Pass	N/A	Pass				
103	Canon	PIXMA iP2500	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
104	Canon	PIXMA iP2600	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
105	Canon	PIXMA iP3600	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
106	Canon	PIXMA iP3680	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
107	Canon	PIXMA iP4200	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
108	Canon	PIXMA iP4600	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
109	Canon	PIXMA iP4760	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
110	Canon	PIXMA iP5000	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
111	Canon	PIXMA iP6700D	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
112	Canon	PIXMA MP110	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
113	Canon	PIXMA MP130	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
114	Canon	PIXMA MP145	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
115	Canon	PIXMA MP150	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
116	Canon	PIXMA MP160	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
117	Canon	PIXMA MP170	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
118	Canon	PIXMA MP180	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
119	Canon	PIXMA MP450	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
120	Canon	PIXMA MP530	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
121	Canon	PIXMA MP638	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
122	Canon	PIXMA MP730	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
123	Canon	PIXMA MP780	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
124	Canon	PIXMA MP830	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
125	Canon	PIXMA MX320	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
126	Canon	MX700	-	-	-	Pass	-	-	-	Pass
127	Canon	MX7600	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
128	Canon	MX850	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
129	Canon	Pixus 990i	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
130	Canon	Pixus MP770	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
131	Canon	Pro9000	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
132	Canon	Pro9000 Mark II	Pass	N/A	N/A	-	Pass	N/A	N/A	-
133	Canon	Pro9500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
134	Canon	Pro9500 Mark II	Pass	N/A	N/A	-	Pass	N/A	N/A	-
135	Dell	Photo 720	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
136	Epson	Aculaser C1000	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
137	Epson	Aculaser C1000SE	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
138	Epson	Aculaser C3000N	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
139	Epson	Aculaser C4000	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
140	Epson	Aculaser C900	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
141	Epson	Aculaser M1200	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
142	Epson	Aculaser M2010DN	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
143	Epson	B-508DN	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
144	Epson	B-518DN	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
145	Epson	AL-C900	Pass	N/A	N/A	Pass	N/A	N/A	N/A	Pass
146	Epson	CC-500L	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
147	Epson	EC-01	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
148	Epson	AL-C1600	Pass	N/A	N/A	Pass				
149	Epson	AL-C1700	Pass	N/A	N/A	Pass				
150	Epson	AL-C1750W	Pass	N/A	N/A	Pass				
151	Epson	AL-C1750N	Pass	N/A	N/A	Pass				
152	Epson	AL-C2900	Pass	N/A	N/A	Pass				
153	Epson	AL-C3900N	Pass	N/A	N/A	Pass				
154	Epson	AL-CX16NF	Pass	Pass	N/A	Pass				
155	Epson	AL-CX17NF	Pass	Pass	N/A	Pass				
156	Epson	AL-MX14NF	Pass	Pass	N/A	Pass				
157	Epson	AL-MX21	Pass	Pass	N/A	Pass				
158	Epson	AL-M1400	Pass	N/A	N/A	Pass				
159	Epson	AL-M2010D	Pass	N/A	N/A	Pass				
160	Epson	AL-M2010DN	Pass	N/A	N/A	Pass				
161	Epson	AL-M2310	Pass	N/A	N/A	Pass				
162	Epson	AL-M2410	Pass	N/A	N/A	Pass				
163	Epson	B-518DN	Pass	N/A	N/A	Pass				
164	Epson	EPL-5800	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
165	Epson	EPL-5800L	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
166	Epson	EPL-5900L	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
167	Epson	EPL-6100L	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
168	Epson	EPL-6200L	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
169	Epson	EPL-N2500	Pass	N/A	N/A	Pass	N/A	N/A	N/A	Pass
170	Epson	K100	Pass	N/A	N/A	Pass				
171	Epson	L200	Pass	Pass	N/A	Pass				
172	Epson	L800	Pass	N/A	N/A	Pass				
173	Epson	LP 2500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
174	Epson	ME320	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
175	Epson	LQ-2190	Pass	N/A	N/A	Pass				

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
176	Epson	ME 320	Pass	Pass	N/A	Pass				
177	Epson	ME 340	Pass	Pass	N/A	Pass				
178	Epson	M188b	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
179	Epson	Perfection 1270	N/A	Pass	N/A	-	N/A	Pass	N/A	-
180	Epson	PLQ-20C	Pass	N/A	N/A	Pass				
181	Epson	PLQ-20CM	Pass	N/A	N/A	Pass				
182	Epson	PM-100	Pass	N/A	N/A	Pass	-	N/A	N/A	Pass
183	Epson	PM-3700C	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
184	Epson	PM-A550	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
185	Epson	PM-A620	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
186	Epson	PM-A650	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
187	Epson	PM-A720	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
188	Epson	PM-A820	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
189	Epson	PM-A840	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
190	Epson	PM-A840S	-	-	-	Pass	-	-	-	Pass
191	Epson	PM-A850	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
192	Epson	PM-A890	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
193	Epson	PM-A900	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
194	Epson	PM-A920	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
195	Epson	PM-A940	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
196	Epson	PM-A950	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
197	Epson	PM-A970	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
198	Epson	PM-FA700	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
199	Epson	PM-G4500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
200	Epson	PM-G5300	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
201	Epson	PM-G860	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
202	Epson	PM-T940	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
203	Epson	PM-T960	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
204	Epson	PM-T990	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
205	Epson	PX-501A	-	-	-	Pass	-	-	-	Pass
206	Epson	PX-5600	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
207	Epson	PX-5800	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
208	Epson	PX-A640	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
209	Epson	PX-A740	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
210	Epson	PX-FA700	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
211	Epson	PX-V780	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
212	Epson	Stylus C43UX	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
213	Epson	Stylus C45	Pass	N/A	N/A	Pass	-	N/A	N/A	Pass
214	Epson	Stylus C60	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
215	Epson	Stylus C61	-	-	-	Pass	-	-	-	Pass
216	Epson	Stylus C65	-	-	-	Pass	-	-	-	Pass
217	Epson	Stylus C66	Pass	N/A	N/A	Pass	-	N/A	N/A	Pass
218	Epson	Stylus C67	-	-	-	Pass	-	-	-	Pass
219	Epson	Stylus C90	-	-	-	Pass	-	-	-	Pass
220	Epson	Stylus CX11F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
221	Epson	Stylus CX-1500	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
222	Epson	Stylus Color 670	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
223	Epson	Stylus CX2900	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
224	Epson	Stylus CX3100	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
225	Epson	Stylus CX3500	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
226	Epson	Stylus CX3700	-	-	-	Pass	-	-	-	Pass
227	Epson	Stylus CX3810	Pass	Pass	N/A	Pass	-	-	N/A	Pass
228	Epson	Stylus CX3900	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
229	Epson	Stylus CX4700	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
230	Epson	Stylus CX4800	Pass	-	-	Pass	-	-	-	Pass
231	Epson	Stylus CX4900	Pass	Pass	-	-	Pass	Pass	-	-
232	Epson	Stylus CX5300	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
233	Epson	Stylus CX5500	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
234	Epson	Stylus CX5505	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
235	Epson	Stylus CX5700F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
236	Epson	Stylus CX5900	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
237	Epson	Stylus CX6900F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
238	Epson	Stylus CX7300	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
239	Epson	Stylus CX7800	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
240	Epson	Stylus CX8300	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
241	Epson	Stylus CX9300F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
242	Epson	ME Office 82WD	Pass	N/A	N/A	Pass				
243	Epson	ME Office 900WD	Pass	Pass	Pass	Pass				
244	Epson	ME Office 940FWD	Pass	Pass	Pass	Pass				
245	Epson	ME Office 960FWD	Pass	Pass	Pass	Pass				
246	Epson	Stylus Office TX320F	Pass	Pass	N/A	Pass				
247	Epson	Stylus CX7803	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
248	Epson	Stylus EC-01	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
249	Epson	Stylus Office TX300F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
250	Epson	Stylus Office TX510F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
251	Epson	Stylus Office TX600F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
252	Epson	Stylus Office TX610F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
253	Epson	Stylus Office TX700F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
254	Epson	Stylus Office TX800F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
255	Epson	Stylus Photo 1270	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
256	Epson	Stylus Photo 2200	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
257	Epson	Stylus Photo 830	Pass	N/A	N/A	Pass	-	N/A	N/A	-
258	Epson	Stylus Photo 915	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
259	Epson	Stylus Photo TX820FWD	Pass	Pass	Pass	Pass				
260	Epson	Stylus Photo R270	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
261	Epson	Stylus Photo RX210	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
262	Epson	Stylus Photo RX430	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
263	Epson	Stylus Photo RX510	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
264	Epson	Stylus Photo RX530	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
265	Epson	Stylus Photo RX630	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
266	Epson	Stylus Photo RX650	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
267	Epson	Stylus Photo RX690	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
268	Epson	Stylus Photo T50	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
269	Epson	Stylus Photo TX700W	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
270	Epson	Stylus Photo TX800FW	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
271	Epson	Stylus R310	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
272	Epson	Stylus R320	Pass	N/A	Pass	Pass	-	N/A	Pass	Pass
273	Epson	Stylus RX510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
274	Epson	Stylus RX530	Pass	Pass	Pass	-	Pass	Pass	Pass	Pass
275	Epson	Stylus RX590	Pass	Pass	Pass	-	-	-	-	-
276	Epson	Stylus T22	Pass	N/A	N/A	Pass				
277	Epson	Stylus TX130	Pass	Pass	N/A	Pass				
278	Epson	Stylus TX220	Pass	Pass	Pass	Pass				
279	Epson	Stylus TX235	Pass	Pass	Pass	Pass				
280	Epson	Stylus TX420W	Pass	Pass	Pass	Pass				
281	Epson	StylusT21	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
282	Epson	StylusT22	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
283	Epson	StylusTX100	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
284	Epson	StylusTX110	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
285	Epson	StylusTX200	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
286	Epson	StylusTX210	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
287	Epson	StylusTX220	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
288	Epson	StylusTX410	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
289	Epson	StylusTX420W	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
290	Epson	StylusTX510FN	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
291	Epson	StylusTX550W	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
292	Epson	StylusTX610FW	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
293	Epson	Workforce T1100	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
294	FUJI Xerox	DocuPrint 120	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
295	FUJI Xerox	DocuPrint 203A	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
296	FUJI Xerox	DocuPrint 240A	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
297	FUJI Xerox	DocuPrint C2090FS	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
298	FUJI Xerox	DocuPrint C525A	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
299	Fuji Xerox	Docuprint P205 b	Pass	N/A	N/A	Pass				
300	FUJI Xerox	WorkCentre3119	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
301	HITI	640AMPHI	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
302	HITI	640DL	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
303	HITI	640GALA	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
304	HITI	640GOLD	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
305	HITI	640PS	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
306	HITI	641PS	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
307	HITI	730PL	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
308	HITI	730PS/GALA	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
309	HITI	S400	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
310	HP	CLJ CM1312MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A



## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
311	HP	Color LaserJet1500L	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
312	HP	Color LaserJet 2025N	Pass	-	-	-	Pass	-	-	-
313	HP	Color LaserJet2600N	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
314	HP	Color LaserJet2840	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
315	HP	Color LaserJet3500	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
316	HP	Color LaserJet3600	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
317	HP	DeskJet D1560	Pass	Pass	N/A	Pass	Pass	N/A	Pass	Pass
318	HP	DeskJet D2460	Pass	Pass	N/A	Pass	Pass	N/A	Pass	Pass
319	HP	DeskJet D2560	Pass	Pass	N/A	Pass	Pass	N/A	Pass	Pass
320	HP	DeskJet D4260	Pass	Pass	N/A	Pass	Pass	N/A	Pass	Pass
321	HP	DeskJet D5560	Pass	Pass	N/A	Pass	Pass	N/A	Pass	Pass
322	HP	DeskJet F4280	Pass	Pass	N/A	Pass	Pass	N/A	Pass	Pass
323	HP	DeskJet F4480	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
324	HP	LaserJet 1005	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
325	HP	LaserJet 1012	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
326	HP	LaserJet 3020	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
327	HP	LaserJet 3030	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
328	HP	LaserJet 3050Z	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
329	HP	LaserJet 3055	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
330	HP	LaserJet 3200	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
331	HP	LaserJet 3300	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
332	HP	LaserJet 3380	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
333	HP	LaserJet 5200L	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
334	HP	LaserJet M1120 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
335	HP	LaserJet M1120N	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
336	HP	LaserJet M1319F MFP	Pass	Pass	Pass	Pass***	Pass	Pass	Pass	Pass***
337	HP	LaserJet P1005	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
338	HP	LaserJet P1006	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
339	HP	LaserJet P1505	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
340	HP	LaserJet P2014	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
341	HP	LaserJet P2015D	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
342	HP	LaserJet P3005D	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
343	HP	OfficeJet 4110	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
344	HP	OfficeJet 4355	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
345	HP	OfficeJet 6000	Pass	Pass	N/A	Pass	Pass	N/A	Pass	Pass
346	HP	OfficeJet 6110	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
347	HP	Officejet 6310	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
348	HP	Officejet 6500	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
349	HP	OfficeJet 6610	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
350	HP	OfficeJet 7000	Pass	Pass	N/A	Pass	Pass	N/A	Pass	Pass
351	HP	OfficeJet 7130	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
352	HP	OfficeJet D165	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
353	HP	Officejet H470b	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
354	HP	OfficeJet J3608	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
355	HP	Officejet J4580	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A



## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
356	HP	OfficeJet J5780	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
357	HP	Officejet J6480	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
358	HP	OfficeJet K80	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
359	HP	Officejet Pro 8000	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
360	HP	Officejet Pro 8500W	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
361	HP	Officejet Pro L7590	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
362	HP	PhotoSmart A520	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
363	HP	PhotoSmart B109a	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
364	HP	PhotoSmart C309a	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
365	HP	PhotoSmart C4180	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
366	HP	PhotoSmart C4280	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
367	HP	PhotoSmart C4385	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
368	HP	PhotoSmart C4480	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
369	HP	PhotoSmart C4580	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
370	HP	PhotoSmart C5180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
371	HP	PhotoSmart C5380	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
372	HP	PhotoSmart C6180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
373	HP	PhotoSmart C6280	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
374	HP	PhotoSmart C6380	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
375	HP	PhotoSmart C7180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
376	HP	PhotoSmart C7280	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
377	HP	PhotoSmart C8180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
378	HP	PhotoSmart D5360	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
379	HP	PhotoSmart D5460	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
380	HP	PhotoSmart D7360	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
381	HP	PhotoSmart Plus B209a	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
382	HP	PhotoSmart Premium C309a	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
383	HP	PhotoSmart Premium C309g	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
384	HP	PSC 1510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
385	HP	PSC 2110	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
386	HP	PSC 2310	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
387	HP	PSC 2355	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
388	HP	PSC 2410	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
389	HP	PSC 2510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
390	HP	PSC 950	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
391	HP	Color Laserjet 2700N	Pass	N/A	N/A	Pass				
392	HP	Color Laserjet CM1015 MFP	Pass	N/A	N/A	Pass				
393	HP	Color Laserjet CP1215	Pass	N/A	N/A	Pass				
394	HP	Deskjet 1125C	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
395	HP	Deskjet 1180C	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
396	HP	Deskjet 1220C	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
397	HP	Deskjet 3745	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
398	HP	Deskjet 5652	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
399	HP	Deskjet 640C	Pass	N/A	N/A	Pass	N/A	N/A	N/A	Pass
400	HP	Deskjet 830C	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
401	HP	Deskjet 920C	Pass	N/A	N/A	-	Pass	N/A	N/A	-
402	HP	Deskjet D2360	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
403	HP	Deskjet 2000 J210	Pass	N/A	N/A	Pass				
404	HP	Deskjet 3000	Pass	N/A	N/A	Pass				
405	HP	Deskjet 3050	Pass	N/A	N/A	Pass				
406	HP	Deskjet D1560	Pass	N/A	N/A	Pass				
407	HP	Deskjet D2360	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
408	HP	Deskjet D2460	-	-	-	Pass	-	-	-	Pass
409	HP	Deskjet D2560	Pass	N/A	N/A	Pass				
410	HP	Deskjet D3745	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
411	HP	Deskjet D4160	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
412	HP	Deskjet D4260	-	-	-	Pass	-	-	-	Pass
413	HP	Deskjet D4360	Pass	N/A	N/A	Pass				
414	HP	Deskjet D4160	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
415	HP	Deskjet F300	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
416	HP	Deskjet F340	Pass	-	-	Pass	Pass	-	-	Pass
417	HP	Deskjet F350	Pass	-	-	Pass	Pass	-	-	Pass
418	HP	Deskjet F370	Pass	-	-	Pass	Pass	-	-	Pass
419	HP	Deskjet F379	Pass	-	-	Pass	Pass	-	-	Pass
420	HP	Deskjet F380	Pass	-	-	Pass	Pass	-	-	Pass
421	HP	Deskjet F4185	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
422	HP	Deskjet F4280	Pass	Pass	N/A	Pass				
423	HP	Deskjet F4480	Pass	Pass	N/A	Pass				
424	HP	LaserJet 1000	Pass	N/A	N/A	-	N/A	N/A	N/A	-
425	HP	LaserJet 1010	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
426	HP	LaserJet 1015	Pass	-	-	Pass	Pass	-	-	N/A
427	HP	LaserJet 1018	Pass	N/A	N/A	NS	Pass	N/A	N/A	NS
428	HP	LaserJet 1020	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
429	HP	LaserJet 1022	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
430	HP	LaserJet 1160	Pass	N/A	N/A	NS	Pass	N/A	N/A	NS
431	HP	LaserJet 2420	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
432	HP	LaserJet 2600n	Pass	N/A	N/A	-	-	N/A	N/A	-
433	HP	LaserJet 3015	Pass	Pass	N/A	-	Pass	Pass	N/A	-
434	HP	LaserJet 3050	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
435	HP	LaserJet 3330	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
436	HP	LaserJet M1005	Pass	Pass	N/A	N/A	Pass	Pass	N/A	Pass
437	HP	LaserJet Pro P1102w	Pass	N/A	N/A	-	Pass	N/A	N/A	-
438	HP	LaserJet Pro M1132	Pass	Pass	N/A	-	Pass	Pass	N/A	-
439	HP	LaserJet M152n MFP	Pass	Pass	N/A	Pass				
440	HP	Officejet 4255	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
441	HP	Officejet 4500	Pass	Pass	N/A	Pass				
442	HP	Officejet 5510	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
443	HP	Officejet 5610	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
444	HP	Officejet 6000	Pass	N/A	N/A	Pass				

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
445	HP	Officejet 6210	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
446	HP	Officejet 6500	Pass	Pass	Pass	Pass				
447	HP	Officejet 7210	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
448	HP	Officejet 7500A	Pass	Pass	Pass	Pass				
449	HP	Officejet J3608	Pass	Pass	N/A	Pass				
450	HP	Officejet J4580	Pass	Pass	N/A	Pass				
451	HP	Officejet J4660	Pass	Pass	N/A	Pass				
452	HP	Officejet J5780	Pass	Pass	N/A	Pass				
453	HP	Officejet J6480	Pass	Pass	Pass	Pass				
454	HP	Officejet G85	Pass	Pass	N/A	-	Pass	Pass	N/A	-
455	HP	Officejet Pro 6500A	Pass	Pass	Pass	Pass				
456	HP	Officejet Pro 7000	Pass	N/A	N/A	Pass				
457	HP	Officejet Pro 8000	Pass	N/A	N/A	Pass				
458	HP	Officejet Pro 8500A	Pass	Pass	Pass	Pass				
459	HP	Officejet Pro 8500W	Pass	Pass	Pass	Pass				
460	HP	Officejet Pro L7380	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
461	HP	Officejet Pro L7590	Pass	Pass	Pass	Pass				
462	HP	Officejet Pro K5300	Pass	N/A	N/A	Pass				
463	HP	Officejet Pro K8600	Pass	N/A	N/A	Pass				
464	HP	PhotoSmart 2610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
465	HP	PhotoSmart 3110	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
466	HP	PhotoSmart 3210	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
467	HP	PhotoSmart 3310	-	-	-	Pass	-	-	-	Pass
468	HP	PhotoSmart 335	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
469	HP	PhotoSmart 7830	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
470	HP	PhotoSmart 8030	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
471	HP	PhotoSmart A310	Pass	N/A	N/A	-	Pass	N/A	N/A	-
472	HP	PhotoSmart A520	Pass	N/A	N/A	Pass				
473	HP	PhotoSmart B109a	Pass	Pass	Pass	Pass				
474	HP	PhotoSmart B109n	Pass	Pass	Pass	Pass				
475	HP	PhotoSmart B110a AIO	Pass	Pass	Pass	Pass				
476	HP	PhotoSmart B209a	Pass	Pass	Pass	Pass				
477	HP	PhotoSmart B210a	Pass	Pass	Pass	Pass				
478	HP	PhotoSmart C309a	Pass	Pass	Pass	Pass				
479	HP	PhotoSmart Plus C310a	Pass	Pass	Pass	Pass				
480	HP	PhotoSmart Premium	Pass	Pass	Pass	Pass				
481	HP	PhotoSmart C410a	Pass	Pass	Pass	Pass				
482	HP	PhotoSmart C3180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
483	HP	PhotoSmart C4180	Pass	Pass	Pass	Pass				
484	HP	PhotoSmart C4280	Pass	Pass	Pass	Pass				
485	HP	PhotoSmart C4380	Pass	Pass	Pass	Pass				
486	HP	PhotoSmart C4480	Pass	Pass	Pass	Pass				
487	HP	PhotoSmart C4580	Pass	Pass	Pass	Pass				
488	HP	PhotoSmart C5180	Pass	Pass	Pass	Pass				

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
489	HP	PhotoSmart C5280	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
490	HP	PhotoSmart C5380	Pass	Pass	Pass	Pass				
491	HP	PhotoSmart C6180	Pass	Pass	Pass	Pass				
492	HP	PhotoSmart C6280	Pass	Pass	Pass	Pass				
493	HP	PhotoSmart C6380	Pass	Pass	Pass	Pass				
494	HP	PhotoSmart C7180	Pass	Pass	Pass	Pass				
495	HP	PhotoSmart C7280	Pass	Pass	Pass	Pass				
496	HP	PhotoSmart C8180	Pass	Pass	Pass	Pass				
497	HP	PhotoSmart D5360	Pass	N/A	Pass	Pass				
498	HP	PhotoSmart D5460	Pass	N/A	Pass	Pass				
499	HP	PhotoSmart D7360	Pass	N/A	Pass	Pass				
500	HP	PhotoSmart P1000	Pass	N/A	Pass	-	Pass	N/A	Pass	-
501	HP	PSC 1210	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
502	HP	PSC 1315	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
503	HP	PSC 1350	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
504	HP	PSC 1402	Pass	Pass	-	Pass	Pass	Pass	-	Pass
505	HP	PSC 1410	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
506	HP	PSC 1610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
507	HP	PSC 2210 All-in-one	Pass	Pass	Pass	-	Pass	Pass	Pass	-
508	HP	Scanjet 4200C	N/A	Pass	N/A	-	N/A	Pass*	N/A	-
509	HP	Scanjet 4370	N/A	PASS	N/A	-	N/A	PASS	N/A	-
510	IBM	Infoprint 1332	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
511	Konica Minota	MC-2430DL	Pass	N/A	N/A	-	-	N/A	N/A	-
512	Konica Minota	Bizhub 160F	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
513	Konica Minota	Bizhub 162	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
514	Konica Minota	Bizhub 210	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
515	Konica Minota	Dialta Di1611	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
516	Konica Minota	MagiColor 2300W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
517	Konica Minota	MagiColor 2400W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
518	Konica Minota	MagiColor 2430DL	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
519	Konica Minota	Magicolor 2500W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
520	Konica Minota	MagiColor 5430DL	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
521	Konica Minota	MagiColor 5440DL	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
522	Konica Minota	PagePro 1250W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
523	Konica Minota	PagePro 1300W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
524	Konica Minota	PagePro 1350W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
525	Konica Minota	PagePro 1380MF	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
526	Konica Minota	PagePro 1390MF	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
527	Konica Minota	PagePro 1400W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
528	KYOCERA	FS-720	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
529	KYOCERA	FS-1300D	-	-	-	Pass	-	-	-	Pass
530	KYOCERA	KM-1635	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
531	KYOCERA	KM-2035	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
532	KYOCERA	P3150	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
533	Lexmark	C750	Pass	N/A	N/A	-	Pass	N/A	N/A	-

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
534	Lexmark	E120	Pass	N/A	N/A	-	Pass	N/A	N/A	-
535	Lexmark	E210	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
536	Lexmark	P3150	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
537	Lexmark	P4350	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
538	Lexmark	P6250	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
539	Lexmark	P707	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
540	Lexmark	P915	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
541	Lexmark	X1150	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
542	Lexmark	X1185	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
543	Lexmark	X1195	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
544	Lexmark	X1270	Pass	Pass*	N/A	NS	Pass	Pass*	N/A	NS
545	Lexmark	X2250	Pass	Pass	N/A	N/A	Pass	Pass	N/A	Pass
546	Lexmark	X2350	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
547	Lexmark	X2650	Pass	Pass	-	NS	Pass	Pass	-	NS
548	Lexmark	X3330	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
549	Lexmark	X3350	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
550	Lexmark	X3470	Pass	Pass*	Pass	NS	Pass	Pass*	Pass	NS
551	Lexmark	X3550	Pass	Pass*	Pass	NS	Pass	Pass*	Pass	NS
552	Lexmark	X4250	Pass	Pass	-	NS	Pass	Pass	-	NS
553	Lexmark	X4270	Pass	Pass	-	NS	Pass	Pass	-	NS
554	Lexmark	X5150	Pass	Pass	N/A	-	Pass	Pass*	N/A	-
555	Lexmark	X5250	Pass	Pass	N/A	-	Pass	Pass*	N/A	-
556	Lexmark	X5270	Pass	Pass	N/A	-	Pass	Pass*	N/A	-
557	Lexmark	X5470	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
558	Lexmark	X5495	Pass	Pass	-	-	Pass	Pass	-	-
559	Lexmark	X6150	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
560	Lexmark	X6170	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
561	Lexmark	X7170	Pass	Pass*	N/A	NS	Pass	Pass*	N/A	NS
562	Lexmark	X7350	Pass	Pass*	N/A	NS	Pass	Pass*	N/A	NS
563	Lexmark	X8350	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
564	Lexmark	X85	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
565	Lexmark	Z1350	Pass	-	-	-	Pass	-	-	-
566	Lexmark	Z43	Pass	N/A	N/A	Pass	N/A	N/A	N/A	N/A
567	Lexmark	Z605	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
568	Lexmark	Z645	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
569	Lexmark	Z705	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
570	Lexmark	Z816	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
571	Lexmark	Z55	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
572	Minota	E120	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
573	OKI	B4100	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
574	OKI	B4351	N/A	N/A	N/A	N/A	Pass	N/A	N/A	Pass
575	OKI	C3200	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
576	OKI	C5600n	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
577	OKI	C5800n	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
578	OKI	Page 8W	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A

## MFP / Printer / Scanner

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
579	RICOH	Afcio MP 1600	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
580	RICOH	Gestetner MP 1600L	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
581	RICOH	Gestetner MP 2000L	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
582	Samsung	CLP-315	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
583	Samsung	CLP-620ND	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
584	Samsung	CLX-2160	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
585	Samsung	CLX-3175	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
586	Samsung	Laser MFP SF-560	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
587	Samsung	Laser MFP SF-565P	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
588	Samsung	ML-1210	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
589	Samsung	ML-1610	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
590	Samsung	ML-1660	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
591	Samsung	CLX-2160	Pass	Pass	N/A	Pass				
592	Samsung	ML-1610	Pass	N/A	N/A	Pass				
593	Samsung	ML-1660	Pass	N/A	N/A	Pass				
594	Samsung	ML-1710	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
595	Samsung	ML-1750	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
596	Samsung	ML-2010	Pass	N/A	N/A	Pass	Pass	N/A	N/A	NS
597	Samsung	ML-2580N	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
598	Samsung	ML-3471ND	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
599	Samsung	ML-2580	Pass	N/A	N/A	Pass				
600	Samsung	ML-3471ND	Pass	N/A	N/A	Pass				
601	Samsung	CLP-315	Pass	N/A	N/A	Pass				
602	Samsung	CLP-620ND	Pass	N/A	N/A	Pass				
603	Samsung	SCX 4016	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
604	Samsung	SCX-4100	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
605	Samsung	SCX-4106	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
606	Samsung	SCX-4116	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
607	Samsung	SCX-4200	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
608	Samsung	SCX-4216F	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
609	Samsung	SCX 4500	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
610	Samsung	SCX-4521F	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
611	Samsung	SCX-4720F	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
612	SHARP	AM-400	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
613	SHARP	AR-5316	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
614	SHARP	AR-M205	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
615	SHARP	AR-M207	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
616	SHARP	AR-M209	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
617	SHARP	AR-M276	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
618	TECO	DOCUJET 3516	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
619	TECO	DOCUJET 4016	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
620	TECO	DOCUJET 4021	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
621	TECO	DOCUJET UA-1610F	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
622	TECO	DOCUJET UA3816	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
623	TECO	DOCUJET UA3820	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A

**MFP / Printer / Scanner**

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
624	TOSHIBA	Estudio-165	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A

**N/A : This USB Device does not have this function**

**- : Not Test (Only a certain function of this device was tested)**

**NS: This function is not supported.**

Remark:

1. Scan: Pass\* means pass either by Utility Scan or MS Paint Scan



## TL-PS310U Compatibility List

Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others							
No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
<b>Hard Disk</b>							
1	Airlink	USB Enclosure (AEN-U55)	Pass	Pass	-	-	
2	Benq	EW1621	Pass	Pass	-	-	
3	Buffalo	HD-PH80U2/UC-BK	Pass	Pass	Pass	Pass	
4	Corega	CG-U2HDC25	Pass	Pass	-	-	
5	Cypress	Cypress Semiconductor USB2.0 St	Pass	Pass	Pass	Pass	
6	Edge	EDGDC-196318-PE DiskGO 20GB	Pass	Pass	Pass	Pass	
7	Genuine	Scopio	Pass	Pass	-	-	
8	Hitachi	2.5" USB HDD	Pass	Pass	Pass	Pass	
9	Initio	MHW2160BH PL	Pass	Pass	Pass	Pass	
10	IO Data	HDPG-SU80	Pass	Pass	-	-	
11	IOGear	eSATA/USB2.0	Pass	Pass	Pass	Pass	
12	IOGear	Firewire / USB 2.0 External HDD	Pass	Pass	NS	NS	
13	Jmicron	USB to ATA/ATAPI Bridge	Pass	Pass	Pass	Pass	
14	LaCie	Starck desktop 1TB 3.5 inches	Pass	Pass	Pass	Pass	
15	Logitec	LHD-ED1000FU2	Pass	Pass	Pass	Pass	
16	Logitec	LHD-ED1000SAU2	Pass	Pass	Pass	Pass	
17	Logitec	LHD-ED1000U2	Pass	Pass	Pass	Pass	
18	Logitec	LHD-ED250FU2	Pass	Pass	Pass	Pass	
19	Logitec	LHD-ED250SAU2	Pass	Pass	Pass	Pass	
20	Logitec	LHD-ED250U2	Pass	Pass	Pass	Pass	
21	Logitec	LHD-ED300FU2	Pass	Pass	Pass	Pass	
22	Logitec	LHD-ED300U2	Pass	Pass	Pass	Pass	
23	Logitec	LHD-ED320SAU2	Pass	Pass	Pass	Pass	
24	Logitec	LHD-ED320U2	Pass	Pass	Pass	Pass	
25	Logitec	LHD-ED400FU2	Pass	Pass	Pass	Pass	
26	Logitec	LHD-ED400SAU2	Pass	Pass	Pass	Pass	
27	Logitec	LHD-ED400U2	Pass	Pass	Pass	Pass	
28	Logitec	LHD-ED500FU2	Pass	Pass	Pass	Pass	
29	Logitec	LHD-ED500SAU2	Pass	Pass	Pass	Pass	
30	Logitec	LHD-ED500U2	Pass	Pass	Pass	Pass	
31	Logitec	LHD-ED640FU2	Pass	Pass	Pass	Pass	
32	Logitec	LHD-ED640SAU2	Pass	Pass	Pass	Pass	
33	Logitec	LHD-ED640U2	Pass	Pass	Pass	Pass	
34	Logitec	LHD-ED750FU2	Pass	Pass	Pass	Pass	
35	Logitec	LHD-ED750SAU2	Pass	Pass	Pass	Pass	
36	Logitec	LHD-ED750U2	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
37	Logitec	LHD-HB250FU2	Pass	Pass	Pass	Pass	
38	Logitec	LHD-HB250U2	Pass	Pass	Pass	Pass	
39	Logitec	LHD-HB300FU2	Pass	Pass	Pass	Pass	
40	Logitec	LHD-HB300U2	Pass	Pass	Pass	Pass	
41	Logitec	LHD-HB320FU2	Pass	Pass	Pass	Pass	
42	Logitec	LHD-HB320U2	Pass	Pass	Pass	Pass	
43	Logitec	LHD-HB400FU2	Pass	Pass	Pass	Pass	
44	Logitec	LHD-HB400U2	Pass	Pass	Pass	Pass	
45	Logitec	LHD-HB500FU2	Pass	Pass	Pass	Pass	
46	Logitec	LHD-HB500U2	Pass	Pass	Pass	Pass	
47	Logitec	LHD-HB750FU2	Pass	Pass	Pass	Pass	
48	Logitec	LHD-HB750U2	Pass	Pass	Pass	Pass	
49	Logitec	LHD-HBS100U2	Pass	Pass	Pass	Pass	
50	Logitec	LHD-HBS250FU2	Pass	Pass	Pass	Pass	
51	Logitec	LHD-HBS250SAU2	Pass	Pass	Pass	Pass	
52	Logitec	LHD-HBS250U2	Pass	Pass	Pass	Pass	
53	Logitec	LHD-HBS300FU2	Pass	Pass	Pass	Pass	
54	Logitec	LHD-HBS300SAU2	Pass	Pass	Pass	Pass	
55	Logitec	LHD-HBS300U2	Pass	Pass	Pass	Pass	
56	Logitec	LHD-HBS320FU2	Pass	Pass	Pass	Pass	
57	Logitec	LHD-HBS320SAU2	Pass	Pass	Pass	Pass	
58	Logitec	LHD-HBS320U2	Pass	Pass	Pass	Pass	
59	Logitec	LHD-HBS400FU2	Pass	Pass	Pass	Pass	
60	Logitec	LHD-HBS400SAU2	Pass	Pass	Pass	Pass	
61	Logitec	LHD-HBS400U2	Pass	Pass	Pass	Pass	
62	Logitec	LHD-HBS500FU2	Pass	Pass	Pass	Pass	
63	Logitec	LHD-HBS500SAU2	Pass	Pass	Pass	Pass	
64	Logitec	LHD-HBS500U2	Pass	Pass	Pass	Pass	
65	Logitec	LHD-HBS640U2	Pass	Pass	Pass	Pass	
66	Logitec	LHD-HBS750FU2	Pass	Pass	Pass	Pass	
67	Logitec	LHD-HBS750SAU2	Pass	Pass	Pass	Pass	
68	Logitec	LHD-HBS750U2	Pass	Pass	Pass	Pass	
69	Logitec	LHD-PBE120U2BK	Pass	Pass	Pass	Pass	
70	Logitec	LHD-PBE120U2SV	Pass	Pass	Pass	Pass	
71	Logitec	LHD-PBE120U2WH	Pass	Pass	Pass	Pass	
72	Logitec	LHD-PBE160U2BK	Pass	Pass	Pass	Pass	
73	Logitec	LHD-PBE160U2SV	Pass	Pass	Pass	Pass	
74	Logitec	LHD-PBE160U2WH	Pass	Pass	Pass	Pass	
75	Logitec	LHD-PBE40U2BK	Pass	Pass	Pass	Pass	
76	Logitec	LHD-PBE40U2SV	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
77	Logitec	LHD-PBE40U2WH	Pass	Pass	Pass	Pass	
78	Logitec	LHD-PBE80U2BK	Pass	Pass	Pass	Pass	
79	Logitec	LHD-PBE80U2SV	Pass	Pass	Pass	Pass	
80	Logitec	LHD-PBE80U2WH	Pass	Pass	Pass	Pass	
81	Logitec	LHD-PBF120FU2SV	Pass	Pass	Pass	Pass	
82	Logitec	LHD-PBF160FU2SV	Pass	Pass	Pass	Pass	
83	Logitec	LHD-PBF250FU2SV	Pass	Pass	Pass	Pass	
84	Logitec	LHD-PBF320FU2SV	Pass	Pass	Pass	Pass	
85	Logitec	LHD-PHA120FU2	Pass	Pass	Pass	Pass	
86	Logitec	LHD-PHA120U2	Pass	Pass	Pass	Pass	
87	Logitec	LHD-PHA160FU2	Pass	Pass	Pass	Pass	
88	Logitec	LHD-PHA160U2	Pass	Pass	Pass	Pass	
89	Logitec	LHD-PHA80FU2	Pass	Pass	Pass	Pass	
90	Logitec	LHD-PHA80U2	Pass	Pass	Pass	Pass	
91	Logitec	LHD-PS80U2WH	Pass	Pass	Pass	Pass	
92	Logitec	LHD-PSA120U2SV	Pass	Pass	Pass	Pass	
93	Mastor	Mastor Basics External Hard Drive	Pass	Pass	Pass	Pass	
94	Mastor	Mastor Basics External Hard Drive	Pass	Pass	Pass	Pass	
95	Mobile Disk	HD-338-U2C	Pass	Pass	-	-	
96	NetDisk	NDAS ND10	Pass	Pass	-	-	
97	NuSLIM	PL-2506	Pass	Pass	-	-	
98	Philips	Mobile Storage Drive (300G)	Pass	Pass	Pass	Pass	
99	Philips	USB 2.0 Mobile Disk(SPD5220CC/	Pass	Pass	Pass	Pass	
100	Prolific	Prolific Technology ING (160G)	Pass	Pass	Pass	Pass	
101	RDC	RDC2882	Pass	Pass	-	-	
102	Sunplus	USB to Serial-ATA Bridge	Pass	Pass	Pass	Pass	
103	Teac	HD-231	Pass	Pass	-	-	
104	Transcend	2.5" HDD	Pass	Pass	Pass	Pass	
105	Transcend	StoreJet 2.5" 120G HDD	Pass	Pass	Pass	Pass	
106	Transcend	StoreJet 25C 320GB	Pass	Pass	Pass	Pass	
107	Transcend	StoreJet TS30GSJ18 30GB USB H	Pass	Pass	Pass	Pass	
108	Transcend	StoreJet TS40GSJ25B USB HDD	Pass	Pass	Pass	Pass	
109	Vantec	Nexstar.3 External 3.5" Hard Drive	Pass	Pass	Pass	Pass	
110	VIA	USB to IDE Bridge	Pass	Pass	Pass	Pass	
111	Vipower	VPA-25289	Pass	Pass	-	-	
112	Xander	X-Note 2.5" 160G SATA Mobile Dis	Pass	Pass	Pass	Pass	
113	Zynet	HD-D4-U2SA	Pass	Pass	Pass	Pass	
114	Zynet	HD-D5-U2FW	Pass	Pass	Pass	Pass	
<b>Card Reader</b>							
115	Alcor	Single Slot SD/MMC/SD-HC Card R	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
116	Elecom	MR-A10BK	Pass	Pass	Pass	Pass	
117	Elecom	MR-A10GN	Pass	Pass	Pass	Pass	
118	Elecom	MR-A10GY	Pass	Pass	Pass	Pass	
119	Elecom	MR-A10WH	Pass	Pass	Pass	Pass	
120	Elecom	MR-A11HWH	Pass	Pass	Pass	Pass	
121	Elecom	MR-A13HSV	Pass	Pass	Pass	Pass	
122	Elecom	MR-A14HBK	Pass	Pass	Pass	Pass	
123	Elecom	MR-A14HBU	Pass	Pass	Pass	Pass	
124	Elecom	MR-A14HSV	Pass	Pass	Pass	Pass	
125	Elecom	MR-A14HWH	Pass	Pass	Pass	Pass	
126	Elecom	MR-A20HBK	Pass	Pass	Pass	Pass	
127	Elecom	MR-A20HBU	Pass	Pass	Pass	Pass	
128	Elecom	MR-A20HRD	Pass	Pass	Pass	Pass	
129	Elecom	MR-A20HSV	Pass	Pass	Pass	Pass	
130	Elecom	MR-A20HWH	Pass	Pass	Pass	Pass	
131	Elecom	MR-A33HBK	Pass	Pass	Pass	Pass	
132	Elecom	MR-A33HSV	Pass	Pass	Pass	Pass	
133	Elecom	MR-A33HWH	Pass	Pass	Pass	Pass	
134	Elecom	MR-A47HBK	Pass	Pass	Pass	Pass	
135	Elecom	MR-A47HSV	Pass	Pass	Pass	Pass	
136	Elecom	MR-A47HWH	Pass	Pass	Pass	Pass	
137	Elecom	MR-C10BK	Pass	Pass	Pass	Pass	
138	Elecom	MR-C10SV	Pass	Pass	Pass	Pass	
139	Elecom	MR-C10WH	Pass	Pass	Pass	Pass	
140	Elecom	MR-C11BK	Pass	Pass	Pass	Pass	
141	Elecom	MR-C11RD	Pass	Pass	Pass	Pass	
142	Elecom	MR-C11SV	Pass	Pass	Pass	Pass	
143	Elecom	MR-C11WH	Pass	Pass	Pass	Pass	
144	Elecom	MR-C12BK	Pass	Pass	Pass	Pass	
145	Elecom	MR-C12BU	Pass	Pass	Pass	Pass	
146	Elecom	MR-C12RD	Pass	Pass	Pass	Pass	
147	Elecom	MR-C12WH	Pass	Pass	Pass	Pass	
148	Elecom	MR-C13BK	Pass	Pass	Pass	Pass	
149	Elecom	MR-C13WH	Pass	Pass	Pass	Pass	
150	Elecom	MR-SMC01BK	Pass	Pass	Pass	Pass	
151	Elecom	MR-SSD01BK	Pass	Pass	Pass	Pass	
152	E-Sense	SCR200	Pass	Pass	Pass	Pass	
153	Galileo	23-in-1 Card Reader	Pass	Pass	-	-	
154	Genesys	SD Cad Reader Genesys Logic	Pass	Pass	Pass	Pass	
155	Moai	SDMMC M121	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
156	Myson Century	CF Card Reader USB2.0	Pass	Pass	Pass	Pass	
157	No Brand	6 in 1 Card Reader (CR-V1102-U26	Pass	Pass	Pass	Pass	
158	No Brand	Media Reader USB 2.0	Pass	Pass	Pass	Pass	
159	Philips	SD/Mini SD/MMC Card Reader	Pass	Pass	Pass	Pass	
160	Samsung	TRUTION TUH-7000X	Pass	Pass	-	-	
161	SanDisk	SDDR-113	Pass	Pass	Pass	Pass	
162	Sanwa	ADR-MLT1W	Pass	Pass	Pass	Pass	
163	SMSC	USB to Flash Device	Pass	Pass	Pass	Pass	
164	SUNZone	SUZCR920	Pass	Pass	N/A	N/A	
165	Teac	US-4SM-B	Pass	Pass	-	-	
166	Transcend	TS-RD13B, 13-in-1 Card Reader	Pass	Pass	-	-	
167	VIA	USB2.0 Card Reader	Pass	Pass	Pass	Pass	
<b>VCD / DVD RW</b>							
168	Benq	DVD-RW (EW-1621)	Pass	Pass	Pass	Pass	
169	Benq	DVD-RW (EW-164B)	Pass	Pass	Pass	Pass	
170	Buffalo	DVD Writer (DVSM-XL1218U2)	Pass	Pass	Pass	Pass	
171	IO Data	DVR-UEM16CR	Pass	Pass	-	-	
172	Logitec	LDR-MA18U2	Pass	Pass	-	-	
173	Logitec	LDR-PMD8U2	Pass	Pass	Pass	Pass	
174	Pioneer	Pioneer MULTI Recorder	Pass	Pass	Pass	Pass	
175	Sony	DRX-100UL	Pass	Pass	-	-	
<b>MP3</b>							
176	Apia	APIA MP3 Player	Pass	Pass	Pass	Pass	
177	Apple	iPod 30G	Pass	Pass	Pass	Pass	
178	Apple	iPod Mini	Pass	Pass	-	-	
179	Apple	iPod Video	Pass	Pass	Pass	Pass	
180	Apple	iPod shuffle	-	-	-	-	
181	Apple	iPod nano	-	-	-	-	
182	Apple	iPod classic	-	-	-	-	
183	Apple	iPod touch	-	-	-	-	
184	Apple	iPhone 2G	-	-	-	-	
185	Apple	iPhone 3G	-	-	-	-	
186	Greative	MuVO TX FM	Pass	Pass	Pass	Pass	
187	Isito	IS-901B	Pass	Pass	Pass	Pass	
188	MP4 digitial player	F630	Pass	Pass	Pass	Pass	
189	Mpio	FG100	Pass	Pass	Pass	Pass	
190	Samsung	YP-E3 MP3 Player	Pass	Pass	Pass	Pass	
191	Sony	NW-A806	Pass	Pass	Pass	Pass	
192	Sony	NWD-B103F	Pass	Pass	Pass	Pass	
193	Sony	NW-E013	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
194	Sony	NWZ-S615F	Pass	Pass	Pass	Pass	
<b>Flash Drive</b>							
195	Adata	MyFlash USB2.0 1GB	Pass	Pass	-	-	
196	Adata	MyFlash USB2.0 512MB RB15	Pass	Pass	-	-	
197	Apacer	Handy	Pass	Pass	Pass	Pass	
198	Buffalo	RUF2-S512-BK	Pass	Pass	-	-	
199	Elecom	USB Flash 128MB	Pass	Pass	-	-	
200	IO Data	ToteBag TB-BH512/B	Pass	Pass	-	-	
201	Kingston	DataTraveler 1GB	Pass	Pass	Pass	Pass	
202	Kingston	DataTraveler 2.0 1GB	Pass	Pass	Pass	Pass	
203	Lexar	FireFly (JDFF512-431)	Pass	Pass	-	-	
204	PNY	PNY Attache 2.0	Pass	Pass	Pass	Pass	
205	Pqi	Flash Disk 1G	Pass	Pass	Pass	Pass	
206	SanDisk	Cruzer Contour 4G	Pass	Pass	Pass	Pass	
207	SanDisk	Cruzer Contour 8G	Pass	Pass	Pass	Pass	
208	SanDisk	Cruzer Micro 1G	Pass	Pass	Pass	Pass	
209	SanDisk	Cruzer Micro 4G	Pass	Pass	Pass	Pass	
210	SanDisk	Cruzer Mini 128M	Pass	Pass	Pass	Pass	
211	Slicon Power	Touch Series USB Flash Drive 1G	Pass	Pass	Pass	Pass	
212	Sony	POCKETBIT USM512J	Pass	Pass	-	-	
213	Sony	USM2GJ	Pass	Pass	Pass	Pass	
214	Sony	USM4GJX	Pass	Pass	Pass	Pass	
215	TD Star	TD Star USB Drive	Pass	Pass	Pass	Pass	
216	Transcend	JetFlash 1GB	Pass	Pass	Pass	Pass	
218	Transcend	JetFlash 300 32GB					
217	Transcend	JetFlash 512MB	Pass	Pass	Pass	Pass	
219	Transcend	JF130 1GB	Pass	Pass	Pass	Pass	
220	Transcend	JF168 1GB	Pass	Pass	Pass	Pass	
221	Transcend	JFV30 1GB	Pass	Pass	Pass	Pass	
<b>Floppy Disk</b>							
222	Acer	YD-8U10	Pass	Pass	Pass	Pass	
223	Mitsumi	D343GUE	Pass	Pass	Pass	Pass	
224	Mitsumi	D353FUE	Pass	Pass	Pass	Pass	
225	Mitsumi	USB FDD	Pass	Pass	Pass	Pass	
<b>USB 2.0 Hub</b>							
226	Adaptec	Hi-Speed 4 Ports USB HUB	Pass	Pass	Pass	Pass	
227	GoodTek	GH-201 USB 2.0 4 Ports Hub	Pass	Pass	Pass	Pass	
228	Hewlett-Packard	DG954A 4 Port USB2.0 HUB	Pass	Pass	-	-	
229	I-Rocks	IR-4370 Hub	Pass	Pass	Pass	Pass	
230	KINYO	HUB-3 Pro2007314211459	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
231	No Brand	Mini 4 Ports Hub BP-07000153	Pass	Pass	Pass	Pass	
232	Nstyle	Chip: Genesys Logic Inc	Pass	Pass	Pass	Pass	
233	Samsung	Pleomax PUH-7000X	Pass	Pass	Pass	Pass	
<b>Others</b>							
234	DigiMatelll	INSTEP EX-SRIVE	Pass	Pass	Pass	Pass	Photo Bank
235	MagicPixel	MP612B	Pass*1	Pass*1	Pass*1	Pass*1	Photo Frame
236	Sony	PSP	Pass	Pass	Pass	Pass	PlayStation Portable

**N/A : This USB Device does not have this function**

**- : Not Test (Only a certain function of this device was tested)**

**NS: This function is not supported.**

Remark:

Pass\*1: USB device signal issue, only at full speed.



## USB Audio / USB Phone / USB Display / USB Webcam

No	Brand	Model Name	XP	Vista
<b>USB Audio</b>				
1	3D Sound	PU552	Pass	Pass
2	3D Sound	USB 2.0 3D Audio Sound Card Adapter Virtual 5.1 SC18	Pass	Pass
3	Creative	Labs Sound Blaster Digital Music SX	Pass	Pass
4	ESMT	USB Speaker USB-269A	Pass	Pass
5	Genius	USB Audio Device	Pass	Pass
6	Hewlett-Packard	Multi-media Speakers	Pass	Pass
7	Intopic	Jazz USB Headphone Set	Pass	Pass
8	JS	USB Speaker J-6502	Pass	Pass
9	Kuro	USB Speaker KUP 700	Pass	Pass
10	Lemel	USB Speaker	Pass	Pass
11	Logitech	LRT-FMAM100U	Pass	Pass
12	Logitech	V20 Notebook Speakers	Pass	Pass
13	Mediatek	C-Media USB Headphone Set	Pass	Pass
14	Samsung	USB-335E	Pass	Pass
15	TI	TI USB Audio DAC	Pass	Pass
16	Turtle Beach	Audio Advantage Micro	Pass	Pass
<b>USB Phone</b>				
17	Aipotek	VP-0002	Pass	Pass
18	Corega	Advanced USB Phone CG-USBPH02	Pass	Pass
19	Ipevo	CDPU-04IP	Pass	Pass
<b>USB Display</b>				
20	Asus	UF735	Pass	Pass
21	DisplayLink	DL-120	Pass	Pass
22	DisplayLink	DL-160	Pass	Pass
23	Neonplus	USB2.0 VGA Adapter	Pass	Pass
24	No Brand	UVT100	Pass	Pass
<b>USB WebCam**</b>				
25	Andymay	CD-06 (USB 2.0)	Pass	Pass
26	Andymay	CD-07 (USB 1.1)	Pass	Pass
27	Creative	Live!Cam Video IM Skype Edition (USB 1.1)	Pass	Pass
28	Elecom	UCAM-DLM130	Pass	Pass
29	Elecom	UCAM-DLM130HPN	Pass	Pass
30	Elecom	UCAM-DLM130HSV	Pass	Pass
31	Elecom	UCAM-DLM130HWH	Pass	Pass
32	Elecom	UCAM-DLQ30	Pass	Pass
33	Elecom	UCAM-DLS30HBK	Pass	Pass
34	Elecom	UCAM-DLS30HPN	Pass	Pass
35	Elecom	UCAM-DLS30HSV	Pass	Pass
36	Elecom	UCAM-E130HBU	Pass	Pass
37	Elecom	UCAM-E130HSV	Pass	Pass
38	Elecom	UCAM-E130HWH	Pass	Pass

**USB Audio / USB Phone / USB Display / USB Webcam**

No	Brand	Model Name	XP	Vista
39	Elecom	UCAM-E130HWH	Pass	Pass
40	Empia	JHY107	Pass	Pass
41	Gdmall	Cyber Cam Max (USB 1.1)	Pass	Pass
42	Intopic	Web Live620-W (USB 2.0)	Pass	N/A
43	Intopic	Web Live660-G (USB 1.1)	Pass	Pass
44	Ipevo	Ipevo POV CDVU-02IP	Pass	Pass
45	Kinyo	My EZCam PCM-531 (USB 1.1)	Pass	Pass
46	Logitech	QuickCam Chat(快看分享版)	Pass	Pass
47	Logitech	QuickCam Chat(快看聊天室) (USB 1.1)	Pass	N/A
48	Logitech	QuickCam Communication STX	Pass	Pass
49	Logitech	QuickCam Pro 3000	Pass	N/A
50	Microsoft	LifeCam VX-3000 (USB 1.1)	Pass	Pass
51	Microsoft	LifeCam VX-7000 (USB 2.0)	Pass	Pass
52	Nstyle	NWC-532 (USB 2.0)	Pass	Pass
53	ORITE	MB-630 (USB 1.1)	Pass	N/A
54	Philips	Webcam SPC500NC (USB 1.1)	Pass	Pass
55	Ronald	Digital Camera L-1 (PC222) (USB 2.0)	Pass	Pass
56	T.C.Star	TCB-P262 (USB 2.0)	Pass	Pass
57	T.C.Star	TCB-A322 (USB 2.0)	Pass	Pass
58	TASCORP	JPEG USB Video Camera (USB 1.1)	Pass	N/A
59	V-Gear	TalkCam Live AMVG1-010-063-02-G (USB 1.1)	Pass	Pass

**\*\*Web cam not supported when it connected through a USB Hub.**

**NOTE: If the E1868 product comes with more than one USB port, then it has a build-in USB hub.**

**N/A : This USB Device does not have this function**

**- : Not Test (Only a certain function of this device was tested)**

**NS: This function is not supported.**

## TL-PS310U Compatibility List

DV / DSC / Cell Phone						
No	Brand	Model Name	XP		Vista	
			Read	Wirte	Read	Wirte
<b>DV</b>						
1	Sanyo	VPC-C4	Pass	Pass	-	-
2	Sony	DCR-SR200	Pass	Pass	Pass	Pass
3	Sony	DCR-SR300	Pass	Pass	Pass	Pass
4	Sony	DCR-SR62	Pass	Pass	Pass	Pass
5	Sony	DCR-SR82	Pass	Pass	Pass	Pass
6	Sony	HDR-CX7	Pass	Pass	Pass	Pass
7	Sony	HDR-CX7K	Pass	Pass	Pass	Pass
8	Sony	HDR-SR5	Pass	Pass	Pass	Pass
9	Sony	HDR-SR7	Pass	Pass	Pass	Pass
10	Sony	HDR-SR8	Pass	Pass	Pass	Pass
<b>DSC</b>						
11	AIPTEK	DV M2	Pass	Pass	Pass	Pass
12	Canon	A640	Pass	Pass	Pass	Pass
13	Canon	EOS 350D	Pass	Pass	-	-
14	Canon	IXUS 400	Pass	Pass	-	-
15	Canon	IXUS 500	Pass	Pass	Pass	Pass
16	Canon	IXUS 65	Pass	Pass	Pass	Pass
17	Canon	IXUS 860IS	Pass	Pass	Pass	Pass
18	Canon	PowerShot A640	Pass	Pass	-	-
19	Canon	PowerShot G5	Pass	Pass	Pass	Pass
20	Canon	PowerShot S30	Pass	Pass	-	-
21	Canon	PowerShot S3IS	Pass	Pass	-	-
22	Canon	PowerShot S400	Pass	Pass	-	-
23	Canon	Pro90IS	Pass	Pass	-	-
24	Casio	Exilim EX-Z40	Pass	Pass	-	-
25	Casio	Exilim EX-Z55	Pass	Pass	Pass	Pass
26	Casio	QV-R62	Pass	Pass	-	-
27	Fujifilm	FinePix A310	Pass	Pass	-	-
28	Fujifilm	FinePix S5000	Pass	Pass	-	-
29	Fujifilm	FinePix S602	Pass	Pass	-	-
30	Fujifilm	FinePix S9500	Pass	Pass	Pass	Pass
31	Kodak	CX6330	Pass	Pass	-	-
32	Minolta	DiIMAGE F200	Pass	Pass	Pass	Pass
33	Minolta	DiIMAGE Xt	Pass	Pass	-	-
34	Nikon	Coolpix 3100	Pass	Pass	-	-
35	Nikon	Coolpix 3200	Pass	Pass	-	-
36	Nikon	Coolpix 5900	Pass	Pass	-	-
37	Nikon	D100	Pass	Pass	-	-

DV / DSC / Cell Phone						
No	Brand	Model Name	XP		Vista	
			Read	Wirte	Read	Wirte
38	Nikon	D40	Pass	Pass	-	-
39	Olympus	C-2	Pass	Pass	-	-
40	Olympus	C-720	Pass	Pass	-	-
41	Olympus	C-740	Pass	Pass	-	-
42	Olympus	μ1000	Pass	Pass	-	-
43	Olympus	μ300	Pass	Pass	-	-
44	Olympus	μ410	Pass	Pass	-	-
45	Panasonic	DMC FX1	Pass	Pass	Pass	Pass
46	Panasonic	LUMIX F7 (DMC-F7)	Pass	Pass	-	-
47	Panasonic	LUMIX FX7 (DMC-FX07GT)	Pass	Pass	-	-
48	Panasonic	LUMIX FX9 (DMC-FX9)	Pass	Pass	-	-
49	Panasonic	LUMIX FZ20 (DMC-FZ20)	Pass	Pass	-	-
50	Panasonic	LUMIX LC33	Pass	Pass	-	-
51	Panasonic	LUMIX LX2	Pass	Pass	-	-
52	Pentax	OPTIO M10	Pass	Pass	-	-
53	Richo	Caplio-R4	Pass	Pass	-	-
54	Sony	DSC-H3	Pass	Pass	Pass	Pass
55	Sony	DSC-H5	Pass	Pass	Pass	Pass
56	Sony	DSC-H9	Pass	Pass	Pass	Pass
57	Sony	DSC-P10	Pass	Pass	Pass	Pass
58	Sony	DSC-P200	Pass	Pass	Pass	Pass
59	Sony	DSC-T1	Pass	Pass	Pass	Pass
60	Sony	DSC-T2	Pass	Pass	Pass	Pass
61	Sony	DSC-T200	Pass	Pass	Pass	Pass
62	Sony	DSC-T70	Pass	Pass	Pass	Pass
63	Sony	DSC-T9	Pass	Pass	Pass	Pass
64	Sony	DSC-W1	Pass	Pass	Pass	Pass
65	Sony	DSC-W200	Pass	Pass	Pass	Pass
66	Sony	DSC-W80	Pass	Pass	Pass	Pass
67	Sony	DSLR-A200	Pass	Pass	Pass	Pass
68	Sony	DSLR-A700	Pass	Pass	Pass	Pass
69	Sony	NSC-GC1	Pass	Pass	Pass	Pass
<b>Cell Phone</b>						
70	Nokia	6233	Pass	Pass	Pass	Pass

N/A : This USB Device does not have this function  
- : Not Test (Only a certain function of this device was tested)  
NS: This function is not supported.

<b>Mouse / Keyboard / Joystick</b>				
<b>No</b>	<b>Brand</b>	<b>Model Name</b>	<b>XP</b>	<b>Vista</b>
<b>Mouse</b>				
1	Acer	GM-03024A	Pass	Pass
2	Acer	NB Mouse	Pass	Pass
3	DELL	M056U0	Pass	Pass
4	Detroit	PS/2 + USB Mouse	Pass	Pass
5	HP	M-UAE96	Pass	Pass
6	HP	M-UV94	Pass	Pass
7	IBM	USB Device 04B3	Pass	Pass
8	Lemel	M857C	Pass	Pass
9	Logitech	M-BB48	Pass	Pass
10	Logitech	M-BD53	Pass	Pass
11	Logitech	MX310	Pass	Pass
12	Logitech	USB Mouse M-UAG120	Pass	Pass
13	Logitech	USB Mouse M-UV94	Pass	Pass
14	Logitech	USB Optical Mouse	Pass	Pass
15	Microsoft	Compact Optical Mouse M-000008	Pass	Pass
16	Microsoft	Wheel Mouse Optical USB and PS/2 Compatible X08-71118	Pass	Pass
17	Microsoft	X800898	Pass	Pass
18	Samsung	Acrox USB & PS/2 Mouse	Pass	Pass
19	Samsung	Pleomax PS/2+ USB Mouse	Pass	Pass
<b>Keyboard</b>				
20	BTC	8113W	Pass	Pass
21	BTC	8193C	Pass	Pass
22	Hewlett-Packard	KU-0316	Pass	Pass
23	Intopic	KDB-USB-10W	Pass	-
24	No Brand	PS/2 Mouse & Keyboard Connector to USB	Pass	Pass
<b>Joystick</b>				
25	DragonRise	Generic USB Joystick	Pass	Pass
26	Genesys	Genesys Logic	Pass	-
27	Logitech	Driving Force EX	Pass	Pass
28	Logitech	RumblePad 2 G-UF13	Pass	Pass
29	Logitech	WingMan Formula Force GP	Pass	Pass
30	Logitech	Wingman Strike Force 3D	Pass	Pass

**N/A : This USB Device does not have this function**  
**- : Not Test (Only a certain function of this device was tested)**  
**NS: This function is not supported.**

## USB Server Compatibility List

<b>NO Support</b>		
<b>No</b>	<b>Brand</b>	<b>Model Name</b>
<b>Bluetooth</b>		
1	Gigabyte	Bluetooth USB Dongle
<b>Cell phone</b>		
2	Dopod	585
3	Dopod	818 Pro
4	Nokia	6060
5	Motorola	RAZR V3
6	Sony Ericsson	W910i
<b>Scanner</b>		
7	Canon	CanoScan 5200 F
8	Pempower	WorldCard Ultra
9	Hewlett-Packard	Scanjet 4370